

**WARNING: WIRES NEED TO BE CONNECTED TO DRIVER FOUND IN CANOPY AND SHOULD NOT CONECT DIRECTLY TO POWER SOURCE OR A SHORT MIGHT OCCUR.**

1. Screw tube (N) to the coupler (M);  
tube (O1) to tube (N)  
tube (O) to tube (O1)  
tube (P) to tube (O)
2. Put tube (P) through Stainless steel part (E),  
ceiling pan (D)/ washer (B) and Ground wire (C).  
Then, secure by hex nut (A) till tight  
**remark:** *The above steps need to be done 2 times.*
3. Thread off Nipple (H), then put the glass frame (I)  
to the flat metal (G), then secure by Finial(F) till tight  
**remark:** *The above steps for each glass*

3. Identify the positive and negative brown wires from the lamp: the Brown Smooth Wire with writing and labeled "P" is the positive electrode of the wire. The Brown Rigid Wire labeled "N" is the negative electrode wire.

4. Refer to the picture below for assembly of wire to driver instructions:
  - a. In the canopy you will find two drivers
  - b. Take Brown Smooth Wire (P) from the lamp body that is split into two. Connect one wire to the Red (+) wire and the other to the other Red (+) wire
  - c. Take the Ribbed Brown Wire (N) and connect it to BOTH Black (-) wires from the output side of the driver
  - d. Take both White wires from input side and connect to neutral feed of electrical source
  - e. Take both Black Wire from Input side of driver and connect them to the live electrical source.

**remark:** *The driver is shown outside of the canopy for easy understanding of wire connection. In actuality, this driver is inside the canopy.*

