

# Easy Control w/ Your Smart Phone




It is required to have MagicSing Karaoke App either for iPhone or Android smart phones. This app will provide easy and convenient control for searching and playing.


Search **"Magicsing Karaoke"** on App Store or Google Play




1. Open the app



2. At upper left corner, click ≡ button




3. Click 'Log-in' and register your phone



4. Click 'Voucher registration'




5. Enter your code



6. At this point, you can play karaoke with your phone (without ET30KH)



1. Turn on the hub and your microphone




2. Back to configuration, turn on QR code




On your TV screen, find the QR code at the bottom right



3. Read 'How to use' and click 'Scan QR code'




4. Check if it is connected. If it is not connected, try step 3 again.




5. Once your phone and your microphone are connected, you will see play button next to the song title. If it is disconnected, play button will disappear.

## CHOOSING SONG LIST



1. Click 'Select songlist'



2. Choose your song list

Click play button to play on your TV, or click title to play on your phone.