

Warning:


- Caution - Risk of Shock. This product must be installed in accordance with the applicable installation code by a person familiar with the construction and operation of the product and the hazards involved.
- Make sure all electrical power is turned off while installing the fixture.
- Warning Risk of Electrical Shock - Verify that supply voltage is correct by comparing it with the luminaire label information.
- This luminaire must be adequately grounded for protection against shock hazards and to assure proper operation.
- Disconnect power before servicing.
- Always use correct lamp type and wattages.

LED Products Only:

- LEDs are ESD (Electro Static Discharge) sensitive devices that can be easily damaged if the proper ESD mitigating steps are not taken.
- LEDs are very sensitive to mechanical damage. Caution must be taken to avoid damage to the LEDs.
- ESD or mechanical damage voids all warranties.


INSTRUCTIONS APPLY TO THE FOLLOWING:

76 LED/80 LED/82 LED



Step 1: 76 LED

Remove screws holding LED boards and wireway cover plate. Side shift wireway cover plate and lay aside (Fig. 2).




80 LED

Rotate twist-latch holding LED boards and reflector to loosen. Lift reflector up and lay aside (Fig. 3).

82 LED

Raise (2) spring latch fasteners to release pressure on reflector and LED boards. Side shift reflector and raise off fixture (Fig. 3).



Step 2: 76 LED | 80 LED | 82 LED

Make wiring connections and mount fixture on surface or with VBY hangers.

Step 3: 76 LED

Replace LED boards and wireway cover plate. Secure with screw (Fig. 2).

80 LED

Replace LED boards and reflector. Secure with twist latch (Fig. 3).

82 LED

Replace LED boards and reflector over spring latch fastener. Fold spring latch down to secure (Fig. 3).