

INSTALLATION INSTRUCTIONS
BOL-BLOOM



⚠ WARNING

These products may represent a possible shock or fire hazard if improperly installed or attached in any way. Products should be installed in accordance with these instructions, current electrical codes, and/or the current National Electric Code (NEC).

⚠ WARNING

This product must be installed by a person familiar with the construction and operation of the product and the hazards involved and in accordance with current electrical codes and/or the current National Electric Code (NEC). Consult a local licensed electrician if you are unsure of or have questions about installation.

SAFETY INFORMATION

- Read all instructions before beginning. Save these instructions for future use.
- To reduce the risk of fire, electric shock, or injury to persons, pay close attention to this manual and stay within its guidelines when using this product.
- To reduce the risk of fire, electric shock, or injury to persons, this fixture must be properly grounded.
- This product requires a 120-277V AC power input. Confirm source voltage prior to installation.
- Disconnect supply power at the source prior to installation.
- Do not remove any parts from this fixture. This fixture has no serviceable parts.
- As needed, clean lens with non-abrasive cleaning solution and soft cloth.
- LEDs are bright. Do not look directly into fixtures.
- This product is suitable for use in wet locations and marine environments. It is designed for outdoor use only.
- Do not use this fixture in dimming circuits.
- The bollard should be mounted to a level concrete surface.
- Expansion anchor bolts included are for concrete installation. For all other applications, use anchors suitable for the mounting surface.

INSTALLATION (SEE FIGURE 1):

Disconnect supply power from source prior to installation.

1. Using the fixture base as a template, mark the locations of the four expansion anchor bolts onto the level concrete surface.
2. Install expansion anchors in marked locations.
3. Connect the fixture's lead wires to the supply wires, matching polarity: Black to Black/Hot, White to White/Neutral and Green to Bare/Ground using included wire nuts.
4. Line up bollard base's mounting holes with expansion anchors.
5. Tighten the anchor screws with flat washers and lock washers in place, making sure wires are not pinched in any way.

