

INSTALLATION INSTRUCTIONS

SCO-BURG



⚠ WARNING

These products may represent a possible shock or fire hazard if improperly installed or attached in any way. Products should be installed in accordance with these instructions, current electrical codes, and/or the current National Electric Code (NEC).

⚠ WARNING

This product must be installed by a person familiar with the construction and operation of the product and the hazards involved and in accordance with current electrical codes and/or the current National Electric Code (NEC). Consult a local licensed electrician if you are unsure of or have questions about installation.

SAFETY INFORMATION

- Read all instructions before beginning. Save these instructions for future use.
- To reduce the risk of fire, electric shock, or injury to persons, pay close attention to this manual and stay within its guidelines when using this product.
- To reduce the risk of fire, electric shock, or injury to persons, this fixture must be grounded.
- This product requires a 120-277V AC power input. Confirm source voltage prior to installation.
- Disconnect supply power at the source prior to installation.
- Fixture is designed for installation to 4" recessed round and octagonal junction boxes. Confirm junction box is suitable prior to installation.
- Do not remove any parts from this fixture. This fixture has no serviceable parts.
- LEDs are bright. Do not look directly into fixtures.
- This product is suitable for use in wet locations and is designed for surface mounting only.
- Do not use this fixture with wall dimmers or in dimming circuits. Control On/Off functions via switched branch circuit.

INSTALLATION (SEE FIGURE 1):

Disconnect supply power from source prior to installation.

1. Attach the universal mounting bracket to 4" recessed round or octagonal junction box using the two included #8-32 j-box mounting screws and corresponding washers, making sure ground screw is facing you.
2. Using the Allen wrench included, loosen the two retaining screws (do not remove them) to release the fixture's wall plate and separate the wall plate from the fixture body, being careful not to strain the Green/ground wire.
3. Connect the fixture's lead wires to the supply wires, matching polarity: Black to Black/Hot, White to White/Neutral and Green to Bare/Ground using included wire nuts.
4. Confirm the proper orientation of the wall plate by checking that "↑ TOP ↑" is pointed up.
5. Use the wall plate mounting screws to attach the wall plate to the universal mounting bracket.
6. Replace the fixture body onto the wall plate, being careful not to pinch any wires, and tighten the two retaining screws securely using the Allen wrench.

FIGURE 1

